SPD-S SAMPLING PAD



SPD-20 TOTAL PERCUSSION PAD



SPD-6 PERCUSSION PAD



HPD-15 HANDSONIC

ROLAND PERCUSSION PRODUCTS



Roland®

Add Sampling to Any Percussion Setup!



Integrates easily with your kit

A great alternative to acoustic triggers and a rack sampler, the SPD-S lets you play up to eight sounds using six durable rubber pads and three superb-feeling edge triggers. There are no complicated settings to make. Just record a sound, assign it to a pad and go. Up to 12 minutes of sampling is provided in Long mode, along with CD-quality sampling and easy editing including Truncate and Trigger Mode functions.

Choose from pre-loaded or sampled sounds

With room for 399 User waveforms, the SPD-S can store plenty of samples. Better still, there are also 181 ready-toplay waveforms pre-loaded into User memory. These sounds are unique to the SPD-S and include a variety of acoustic and electronic drums, percussion, sound effects and phrase loops that can be combined with user samples to create the ultimate drum kit. A sampling CD is also included, making it easy to expand the onboard sounds.

Powerful sound creation tools

With 30 multi-effects algorithms and a unique ambience effect, the SPD-S offers endless sound-sculpting tools. Just add an effect and resample the output for quick and easy triggering! Using the Phrase Maker function, you can create custom phrase loops by resampling a pattern being triggered from the pads. And tweaking a sound or effect during performance is easy—just twist the front-panel knobs or use an optional expression pedal.

Expandable and customizable

The SPD-S has a stereo input and can accommodate up to two trigger units for playing a drum pad in either a head or head/rim configuration. And with MIDI In and Out, it makes a great controller and module as well. Drummers will also appreciate being able to assign two waveforms per pad and switch them via velocity or footswitch. The pads and the optional footswitch also make for an easy way to stop sounds, switch Patches and turn effects On or Off.







MULTI-EFFECTS

1	REVERB+GATE (Reverb+Gate)
2	DLYEDREVERB (Delayed Reverb)
3	STEREODELAY (Stereo Delay)
4	SYNC-DELAY (Sync Delay)
5	TAPE-ECHO (Tape Echo)
ô	CHORUS
7	DUVCED

SAMPLING MODE/TIME

	Internal	CompactFlash (approx.)													
	(approx.)	16MB	32MB	64MB	128MB	256MB	512MB								
LONG	12 min.	12 min.	24 min.	48 min.	96 min.	193 min.	386 min.								
STANDARD	6 min.	6 min.	12 min.	24 min.	48 min.	96 min.	193 min.								
FINE	3 min.	3 min.	6 min.	12 min.	24 min.	48 min.	96 min.								

PRE-LOADED SOUNDS

-Phrase- 001 002	Moon Drs Moon Bas		029 030 031	16BtEnd 16BtSnr 16BtCrK		051 052	Haaaay BasSlide		086 087 088-089	CowbBngo CowbMmbo Agogo	x 2	133-135 136 137	Xstick 808Claps 909Claps	x 3
003-004	Moon Gt	x 2				-Percussio			090	SlighBel		138	110Claps	
005	Moon Vo		-S.E			053-054	WndChim	x 2	091-092	AnklBed	x 2	139-140	HndClap	x 2
006	JzStpDrs		032-033	AirDrft	x 2	055	PinChime		093	Shaker	- 1	141	FingSnap	
007	JzStpBas		034	SuperLow		056-057	BelTree	x 2	094	ShakeEgg	- 1	142-146	clubKik	x 5
800	JzStpChd		035	RevoDown		058-059	Crotale	x 2	095	Maracas	- 1	147-148	808Kik	x 2
009	JzStpPad		036	SwepNoiz		060-061	Triang	x 2	096-097	Cabasa	x 2	149	909Kik	
010	JzStpMel		037	VerbyHit		062-063	AccCym	x 2	098-100	Bongo	x 3	150	110Kik	
011	2step Bt		038	RevLASER		064-065	CupChim	x 2	101-103	Conga	x 3	151-152	AcuKik	x 2
012-013	JnglBt	x 2	039	WhtPulse		066	Gong		104-105	Cajon	x 2	153-156	clubHH	x 4
014	Xylo Bkg		040	Sperks		067	Tamtam		106-108	Timble	x 3	157-158	808HH	x 2
015	SynthBkg		041	SldWhstl		068-070	Block	х3	109-112	SpokTom	x 4	159-160	909HH	x 2
016	Org Bkg		042	NoiseTap		071-072	Claves	x 2	113-116	OctTom	x 4	161-162	110HH	x 2
017	HipHpBkg		043	Dolphin		073	Cricket				- 1	163-165	AcuHH	x 3
018	Didgerdo		044	Scratch		074	FlexMtl		-Drums-			166	110 Cym	
019	BongoPtn		045	Hi-Q		075	MtlCrash		117-125	clubSnr	x 9	167-169	Splash	x 3
020	CongaPtn		046	Spd-S		076	Ratchet		126	808Snr	- 1	170-172	Crash	x 3
021	ShakrPtn		047	Welcome		077	Vibraslp		127	909Snr		173	China 16	
022	TablaPtn		048	ComeOn!		078-081	Tmbrn	x 4	128	110Snr	- 1	174-175	Ride	x 2
023-025	16BtPtn	х3	049	UGotGrv		082-083	Cowbell	x 2	129	eSnr		176-178	808Tom	x 3
026-028	16BtFil	х 3	050	Yeaaah		084-085	CowbJam	x 2	130-132	AcuSnr	х 3	179-181	AcuTom	x 3

Convenient CompactFlash storage

The SPD-S works with readily available CompactFlash media—making it easy to expand the onboard sampling time, store

custom sounds, and

Sampling is easy!

Follow these simple steps to record and play a sound.



Connect the source to the Input jack and set the Mic/Line switch



Press PATCH to enter Patch mode and use the [-]/[+] buttons to select



Press SAMPLE and strike the pad where you want the



Press START/STOP and start the source. The SPD-S automatically begins sampling when the input START/STOP again when finished,



even import or export .WAV/AIFF files using your

Mac or PC.

Press SAMPLE and strike the pad where you want the



SAMPLING PAD

REAR VIEW



SPECIFICATIONS

dou's input impedance 10 to forms (LineAmil, *) *Output Level* output: -11 double. In Impedance Output: 1 k ohms Headphones: 47 ohms * 0 dBu = 0.775 Yrms * Mei Patches: 128 Waves (User): 399 (Pre-loaded Sound 181), Card: 500 • Maximum ne 1 min. approx. (Internal Memory, Long Mode) • Effects Multi-Effects (30 Ty Ambience (System) • Display 16 characters, 1 line (backlit LCD) • Connectors C (L/Mono, R, 1/4 inch phone type), Input Jacks (L/Mono, R, 1/4 inch phone type). Sampling CD, Slit Tape, Screws; 2, Hexagon Wrench

Innovative Percussion Pads for Stage and Studio.





Flagship sounds and features

The SPD-20's sound set includes everything from ethnic and world percussion instruments to classic and modern acoustic and electronic drum sounds—700 sounds total! Out of the box, you get 99 Preset Patches and six rhythm loops that can be played via eight high-quality pads with natural response—even when playing with common drumming techniques like rolls and flams.



REAR VIEW



SPECIFICATIONS

• Max. Polyphony 14 voices • Number of Instruments 700 • Internal Memory 99 Patches, 8 Patch Chains • Sound Parameters Instrument, Level, Pitch, Decay, Pan, Curve, Effect Send Level • Effects Reverb, Delay, Chorus, Flanger • Number of Pads 8 • Display 7-segment, 3-character LED • Connectors Output (L/Mono, R), Phones (Stereo), External Trigger Input* x 3 (Dual), Hi-Hat Control/Trigger4 Input* (Dual), MiDI (In, Out), Footswitch (Dual), AC IN *Trigger inputs 1 and 2 accept rim shots from the PD-7, -9, -80R and -120 while inputs 3 and 4 accept rim shots from the PD-7 and -9 • Power Supply AC12V, AC Adaptor • Current Draw 420mA • Dimensions 450 (W) x 350 (D) x 70 (H) mm / 17-3/4 (W) x 13-13/16 (D) x 2-13/16 (H) inches • Weight 2.8 kg /6 lbs. 3 oz. (excl. AC Adaptor) • Accessories BOSS BRA-Series AC Adaptor, Slit Tape

Infinitely expressive

Four external dual-trigger inputs make the SPD-20 compatible with a dedicated hi-hat or kick drum controller and any of Roland's drum pads (including V-Pads $^{\text{TM}}$). The trigger inputs can also be used with acoustic drum triggers for triggering acoustic drums. Other noteworthy features include a velocity-sensitive Layer function, onboard effects and MIDI connections for using the SPD-20 as a controller or sound module.



SPD-6 PERCUSSION PAC

REAR VIEW



SPECIFICATIONS

• Max. Polyphony 4 voices • Number of Instruments 113 • Internal Memory Preset: 16, User: 16
• Number of Pads 6 • Connectors OUTPUT 1 (PHONES) / OUTPUT 2 (MONO), Pedal SW 1/2 (for DP-2, FS-5U) for Kick/Hi-Hat control, MIDI OUT, AC Adaptor • Switches SENS, POWER, BANK x4, NUMBER x4 - Control Volume • Power Supply DC 9V dry battery (AA type x6) or AC Adaptor (BOSS PSA series) • Current Draw 100mA • Dimensions 318 (W) x 241 (D) x 67 (H) mm / 12-9/16 x 9-1/2 x 2-11/16 inches • Weight 1.6 kg, 3 lbs. 9 oz. (incl. Batteries) • Accessories MIDI cable, Battery AA type x6 • Options PSA-Series AC Adaptor (BOSS)

Play it by hand or with sticks

Thanks to its Sensitivity Selection switch, the SPD-6 can be played by hand or using drum sticks. Its compact and easy-to-use design makes it a great choice not only for drummers, but for anyone who wants to add 113 high-quality drum sounds to their music. A total of 16 Preset and 16 User Patches are provided, which can be played using the six rubber pads.

Compact design with room to grow

By connecting two optional footswitches, you can turn the SPD-6 into a super compact and portable electronic drum kit. It even works as a MIDI controller and sound module! Best of all, the SPD-6 can run on AC or battery power, so you can take it anywhere. There's never been an easier way to bring electronic percussion into your music.

Preset Instruments

SPD-20

SPL)-20																						
Bass Drun			:			L33	Vibra Slap		F28-F31	Rek	x 4	J45-J46	Chenchen	x 2	M24	Yang Qin		d11-d12	Scratch Bass Drum	x 2	E41	Monster Drum	
b01-b03	Dry Kick		t27-t28	Room Tom		L34-L38	Agogo	x 5	F32	Bendir		J47-J48	Bali Cymbal		[Southeast	Asia]		d13	Scratch Snare		E42	Can Drum	
b04	Meat Kick		t29-t30	Acoustic Tom		L39	Cabasa		F33	Dawul		J49	Thai Gong		M25	Bonang		d14	Jungle Hat		E43-E46	Wah Guitar	۲4
b05	Pillow Kick		:			L40-L45	Cuica	x 6	[Australia]			J50-J51	Jaws Harp	x 2	M26	Gender		1					
1			t38	TR-808 Tom		L46-L52	Pandeiro	x 7	F34	Clapstick					M27	Saron		d19-d21		х 3		ounds, Human Voice	
b21-b22	Reverb Kick	x 2	t39-t40	TR-909 Tom	x 2	L53-L57	Surdo	x 5	F35	Boomerang			l Percussion		M28	Angklung		d22	Air Blip		n01-n02		(2
b23-b25	Mondo Kick	x 3				L58-L61	Tamborim	x 4	[Others]			001	Sleigh Bell		[Melodic Ins			d23	Techno Snap		n03	Doorbell	
b26-b27	Solid Kick		Hi-Hat Cyr			L62-L65	Samba Whistle	x 4	F36	Bloom Bell		002	Tree Chimes		M29-M30	Gamelan Glass	x 2	d24	Organ Chord		n04	Dog Bark Bird	
: b39-b44	TR-808 Kick		h01-h05 h06-h10	Pop Hi-Hat Real Hi-Hat	x 5 x 5	L66 L67-L70	Cax ix i Berimbau		[Africa] F37	A(1 (10)		o03-o04 o05-o06	Triangle Castanets	x 2 x 2	M31 M32	Iron Hammer		d25 d26	Distortion Guitar Auh Voice		n05 n06	Car Door	
b45-b48	TR-909 Kick	x 6	h11-h12	Brush Hi-Hat		L71-L74	Caix a	x 4 x 4	F37	Afro Loop (*2)		005-006	Wood Block	x 2	M33	Bamboo		d26 d27	Techno Chord		n06	Car Door Car Stop	
b49	TR-909 Kick	x 4	nii-ni2	Brush HI-Hat	x 2	L75	Rain Stick	X 4	Jananasa	Korean/Chinese/		007	Slapstick		M34	Drip		d28	Techno Scene		n08	Horn	
b50	CR-78 Kick	RICK	h26-h29	TR-808 Hi-Hat	x 4	L76	Samba Bateria			Asian Percussion		009-010	Concert Bass Drum		M35-M36	Synth Strings	x 2	d29	Synth Hit		n09	Punch	
550	OTT-70 INICK		h30-h31	TR-909 Hi-Hat	x 2	177	Samba Loop (*2)	١	[Japan]	Asian Fercussion		011-014	Timpani	x 4	M37-M43	Brass	x 7	023	Syntarrin		:	I UIICII	
Snare Dru	m		h32-h33	CR-78 Hi-Hat	x 2	L78	Shaker Loop (*2)		J01	Biwa		015	Church Bell		M44-M52	Choir	x 9	d36	Retro UFO		n13	Machine Gun	
S01-S03	Piccolo Snare	х3							J02	Atarigane		016-018	Percussion Hit	х3	M53-M59	Bass	x 7	d37	Metal Sweep		n14	Pistol	
S04-S06	Beech Snare	x 3	Hi-Hat Cvi	mbal for pedal contr	ol lo	Indian Per	cussion		J03	Hvoshigi		019-024	Orchestra Hit	x 6				d38	Bounce		n15	Siren	
S07-S09	Acoustic Snare	х3	H01-H02	Pop Hi-Hat	x 2	i01	Sarna Bell		J04	Ohkawa					Analog Per	rcussion		d39	Distortion Swish				
S10-S12	Steel Snare	x 3	l :			i02-i06	Baya	x 5	J05-J07	Tsuzumi	х3	Melodic P	ercussion/Melodic		A01	DR-55 Claves		d40	PCM Press		n23	Oww!	
S13-S15	Loose Snare	x 3	H17	Hand Cymbal Hi-H	at	i07-i14	Tabla	x 8	J08-J09	Shime Taiko	x 2	Instrumer	ıts		A02	CR-78 Cowbell		d41	Jungle Roll Kick		n24	Woa!	
S16-S21	Medium Snare	x 6	l			i15-i20	Pot Drum	x 6	J10-J11	Matsuri Taiko	x 2	M01	Glockenspiel		A03	CR-78 Metallic Beat		d42	Jungle Roll Snare		n25	Ooh!	
S22-S26	Concert Snare	x 5	Crash/Rid			i21-i24	Dholak	x 4	J12-J14	Taiko	х3	M02	Vibraphone		A04	CR-78 Guiro		d43	Techno Loop (*2))	n26	Chiki!	
S27	Roll Snare		C01-C04	Crash Cymbal		i25-i27	Madal	х3	J15	Matsuri		M03	x ylophone		A05	CR-78 Tambourine					n27	Hey!	
1			C05-C07	Chinese Cymbal	х3	i28	Khole		J16	Yyoo Dude		M04-M05	Marimba	x 2	A06	CR-78 Maracas		Sound Eff			n28	Ou!	
S39-S45	Brush Snare		:			i29-i32	Dhol	x 4	[Korea]			M06	Bass Marimba		A07	CR-78 Bongo		E01	Burt		n29	Ou! Up	
S46	Rock Snare		C15-C20	Ride Cymbal	x 6	i33	Tabla Baya Loop	(*2)	J17-J18	Buk	x 2	M07	Celesta		A08	CR-78 Claves		E02-E03	Boing	x 2	n30	Scream	
S47	Rocker Snare		C21-C26	Sizzle Ride Cymba	Ix6	l			J19	Jang-Gu		M08-M09	Tubular Bells	x 2	A09	TR-707 Cowbell		E04	Onkey		n31	Voice Loop (*2)	
			ai=	TD 0		African/Mic			J20-J22	Jing	x 3	[Central A			A10	TR-727 Agogo		E05	Tom Noise				
S70-S71 S72-S73	Jungle Snare Electronic Snare	x 2	C35 C36	TR-808 Cymbal TR-606 Cymbal		[Africa]	ıstralian/Other Percu	ission	J23-J25 [China]	Gengari	х 3	M10-M11	Steel Drum	x 2	A11 A12	TR-808 Conga TR-808 Claves		E06 E07	Lazer Feedback Wave			, Reversed Sounds Kick Ambience	
S72-S73 S74-S75	TR-808 Snare	x 2 x 2	C36	I H-606 Cymbal		F01	Shekere		J26-J28	Ban Gu		[India] M12-M13	Sitar	x 2	A12 A13	TR-808 Claves TR-808 Maracas		E07			r01	NICK AMDIENCE	
S74-S75	TR-909 Snare	X-2	Latin Dava	ussion (Cuban, Braz	ilian)	F02-F06	Diembe	x 5	J26-J28 J29-J30	Gu	x 3	M14-M15	Santoor	x 2	A14	TR-808 Maracas		E08	Atmosphere Bend Synth		: r20	Reverse Tom	
S77	TR-909 Share		Latin Perc	Bongo	x 5	F07-F09	Talking Drum	x 3	J29-J30 J31-J32	Tang Gu	x 2	M14-M15	Tambura	x 2	A14 A15	TR-808 Cowbell TR-808 Hand Clap		E10	Toy Gun		120	Heverse 10m	
S78	TR-707 Share		L06-L13	Conga	xs x8	F10-F13	Afro Drum	x 3	J31-J32 J33-J34	Hu Yin Luo	x 2	[Middle Ea		X-2	A16	TR-909 Hand Clap		E10	loy Guil				
S79	CR-78 Snare		I 14-I 18	Conga	x 5	F14	Metal Castanets	× **	J35	Nao Bo	* 2	M18-M19	Hammer Dulcimer	v 2	A10	m-sos nanu ciap		E27-E30	Noise Accent	x 4	(*1): You c	an continuously change	
S80-S86	Cross Stick	x 7	L19-L20	Claves	x 2	[Middle Ea:			J36	x iao Bo		[Africa]	riammer Duicimei	Α.Σ	Dance Sou	inde		E31-E34	Random Noise	v 4		nd length of the sound	
300-300	OTOSS STICK		L21-L22	Guiro	x 2	F15	Bell Tree		J37-J38	Tam-Tam	x 2	M20	Kalimba		d01-d02	Hand Clap	x 2	E35	Slide	^*	from closed	I to opened by using the	
Tom-Tom			L23	Maracas	~-	F16-F17	Sagat	x 2	J39-J42	Gong	x 4	M21	Log Drum		d01-d02	Little Clap		E36	Uut?		hi-hat contr		
t01-t04	Bia Tom	x 4	L24-L26	Shaker	х3	F18-F20	Darbuka	x3	(Southeast			M22	Balaphone		d04	Hip Clap		E37	Drop			are short phrases typical	
t05-t08	Studio Tom	x 4	L27-L28	Tambourine	x 2	F21-F22	Doira	x 2	J43	Finger Cymbal		M23	Afro Zither		d05	Afro Clap		E38	Emergency		nedal swit	sic genre. By using the ch, you can hold the	
			100 100	-		Eco Eco			1000	5		1011			100			E00 E10		-	podai swit	on, you can now me	

SPD-6

Kick Kick Mix Kick Jazz Kick 1 Jazz Kick 1 Jazz Kick 5 MONDO Kick HipHop Kick HipHop Kick 8 808 Kick 1 8 808 Kick 2 9 Electronic Kick	15 Gated Snare 16 808 Snare 17 Electronic Snare 1 18 Electronic Snare 2 19 Cross Stick 20 Snare Roll 21 Brush Roll Snare 22 Brush Swish Snare 23 Brush Slap Snare	30 Room High Tom 31 Room Mid Tom 32 Room Low Tom 33 Power High Tom 1 34 Power High Tom 2 35 Power Mid Tom 1 36 Power Mid Tom 2 37 Power Low Tom 2 38 Power Low Tom 1 38 Power Low Tom 1 39 Power Low Tom 1	47 Electronic Low Tom Hi-Hat Cymbal 48 Closed Hi-Hat [EXC 1] 49 Pedal Hi-Hat [EXC 1] 50 Open Hi-Hat [EXC 1] 51 808 Closed Hi-Hat 1 [EXC 1] 52 806 Closed Hi-Hat 2 [EXC 1] 53 808 Open Hi-Hat [EXC 1]	60 Reverse Cymbal Percussion 61 High Bongo 62 Low Bongo 63 Open High Conga 64 Mute High Conga 65 Low Conga 66 Cowbell 67 Claves	75 Vibra-Slap 76 High Agong 77 Low Agong 78 Open Culea [EXC 3] 79 Mute Culea [EXC 3] 80 Open Surdo [EXC 4] 81 Mute Surdo [EXC 4] 82 Whistle 83 High Wood Block 84 Low Wood Block	Dance Stratch Park Par	104 Door Creaking 105 Door 106 Foot Step 107 Heart Beat 108 Screaming 109 Punch 110 Laughing 111 Thunder 112 Gun Shot 113 Lasergun
Snare	Tom-Tom 24 High Tom 1	40 808 High Tom 2 41 808 Mid Tom 1	Cymbal 54 Crash Cymbal 1	68 Long Guiro [EXC 2] 69 Short Guiro [EXC 2]	85 Bell Tree 86 Open Triangle [EXC 5]	Sound Effects 98 Telephone	
Share 10 Standard Snare 11 Dance Snare 12 HipHop Snare 1 13 HipHop Snare 2 14 Dopin' Snare	24 High Tom 2 25 High Tom 2 26 Mid Tom 1 27 Mid Tom 2 28 Low Tom 1 29 Low Tom 2	41 808 Mid Tom 2 43 808 Low Tom 1 44 808 Low Tom 2 45 Electronic High Tom 46 Electronic Mid Tom	54 Crash Cymbal 1 55 Crash Cymbal 2 56 Splash Cymbal 57 Ride Cymbal 1 58 Ride Cymbal 2 59 808 Cymbal	os short duiro [EXC 2] 70 Maracas 71 Shaker 72 Tambourine 73 High Timbale 74 Low Timbale	86 Open Triangle [EXC 5] 87 Mute Triangle [EXC 5] 88 Metronome Bell 89 Metronome Click	99 Dog 100 Kitty 101 Car-Engine 102 Car-Stop 103 Car-Crash	[EXC*]: Sounds of the same number will not play simultaneously.

A "Hands On" Approach to Electronic Percussion.





HANDSONIC HPD-15

REAR VIEW



SPECIFICATIONS

Maximum Polyphony 64 voices • Instruments Pad Instruments: 600, Backing Instruments: 54 • Preset Patches 160 • User Patches 80 • Patch Chains 10 chains (32 steps per chain) • Effect Type Reverb, Multi-Effects • Sequencer Preset Patterns: 99, User Patterns: 99 (Maximum), Tracks: 4, Play Functions: OneShot, Loop, Tap, Resolution: 96 ticks per quarter note, Recording Method: Real-time • Tempo 20-240 • Display 16 characters; 2 lines (backlit LCD) • Controls Volume Knob, Realtime Modify Knob 1/2/3, Ribbon L/R, D Beam Controller • Pad 10 inches, 15 sections, Pressure-Sensitive • Connectors Output Jacks (L/Mono, R), Phones Jack (stereo), Mix In Jack (stereo), Expression Pedal / Hi-Hat Control Jack, Trigger Input Jack (dual), Foot Switch Jack (dual), MIDI Connectors (IN, OUT/THRU) • Output Impedance 1k ohms • Power Supply AC Adaptor (DC 9V) • Current Draw 1000mA • Dimensions 406 (W) x 405 (D) x 98 (H) mm / 16 (W) x 16 (D) x 3-78 (H) inches • Weight 2.9 kg / 6 lbs 7 oz (Excluding AC Adaptor) • Accessories AC Adaptor (ACI/ACB Series), Label







A dynamic pad with V-Drums technology

Divided into 15 parts, the HPD-15's ultra-sensitive 10-inch rubber pad can be used to trigger up to 15 different sounds using techniques from hard conga slaps to the light finger touch needed for tabla performances. And because the main pad supports positional sensing, you can create timbre changes just by striking different areas of the pad.

Loaded with high-quality sounds

Divided into 15 parts, the HPD-15's ultra-sensitive 10-inch rubber pad can be used to trigger up to 15 different sounds using techniques from hard conga slaps to the light finger touch needed for tabla performances. And because the main pad supports positional sensing, you can create timbre changes just by striking different areas of the pad.

Expressive realtime control

The HPD-15's knobs can be used for controlling pitch, timbre and multi-effects, while dual ribbon controllers create realistic conga slides and make triggering guiro sounds more natural. You can even create rolls by pushing harder on the pads. The D Beam, on the other hand, uses an infrared light beam for adjusting pitch, filter cutoff and triggering sounds like a gong or a bell tone. An optional expression pedal may also be used.

Handy performance features

Perfect for practice or composition, the HPD-15's 4-part pattern sequencer provides 99 Preset and User patterns. And with MIDI In and Out, you can use the HandSonic as a sound module or as the ultimate controller for playing into your sequencer. Live performers will appreciate the ability to add an optional hi-hat controller and kick trigger, as well as the HPD-15's 1/4-inch Line input for blending in external sounds.

Preset Patches & Preset Instruments

PRESET PATCHES

LATIN		AFRICAN		P03 04	Dhol	P04 07	JavaGameln	DRUMS		DANCE		P07 23	DanceMenu1	P09 05	Flute
P01 01	Conga	P02 01	TalkingDrm	P03 05	DrmOfIndia	P04 08	BaliGameln	P06 01	Standard	P07 01	Clap&Scrch	P07 24	DanceMenu2	P09 06	Syn String
P01 02		P02 02	Djembe S	P03 06	MadalTalan	P04 09	Bali&Java	P06 02	Jazzbrush	P07 02	FILTERED			P09 07	Saw Wave
P01 03		P02 03	Djembe L	P03 07	Tabla II	P04 10	Gongs	P06 03	Analog	P07 03	Trash Beat	SFX		P09 08	Juno Rave
P01 04	LatinToys	P02 04	Frame Drum	P03 08	Tabla III	P04 11	Angklung	P06 04	TR-808	P07 04	LatinHouse	P08 01	PsycoDrama	P09 09	Fantasia
P01 05	CONGAbongo	P02 05	Pot Drum	P03 09	TABLATIX	P04 12	Bonang	P06 05	TR-909	P07 05	Techey	P08 02	Forest	P09 10	Thick Pad
P01 06	TimbaleMix	P02 06	Kalimba	P03 10	Sitar	P04 13	Gender	P06 06	Studio	P07 06	TechDance	P08 03	GrandBlue	P09 11	Calliope
P01 07	Conga II	P02 07	Log Drum	P03 11	SantoorMaj	P04 14	Saron	P06 07	Rock Stage	P07 07	EthniDance	P08 04	NoiseSonic	P09 12	Melody-808
P01 08	Bongo II	P02 08	Balaphone	P03 12	SantoorMin	l		P06 08	Swing	P07 08	Cosmo 21	P08 05	ArpegPerc		
P01 09	TimbalesII	P02 09	Gyilli	P03 13	Tambura	ORCH		P06 09	Brushes	P07 09	Industrial	P08 06	CartoonFX	LOOPS	
P01 10	BONGO-BRS-	P02 10	AfroZither	P03 14	Darabukka	P05 01	Vibraphone	P06 10	Orch Set	P07 10	UndaGround	P08 07	Silly FX	P10 01	Latin Loop
P01 11		P02 11	MonguDrum	P03 15	Rek	P05 02	Glockenspl	P06 11	Mexi-Set	P07 11	StreetBeat	P08 08	Rol&FiltMe	P10 02	Samba Loop
P01 12	Steel Drum	P02 12	AfricaToys	P03 16	Doholla	P05 03	Xylophone	P06 12	Hi-Boy	P07 12	909-2000	P08 09	MetalMania	P10 03	AfricaLoop
P01 13	Pandeiro	P02 13	Gyilli&Cng	P03 17	Doira	P05 04	Marimba	P06 13	Low&Dry	P07 13	AlienDance	P08 10	ChaosSonig	P10 04	IndianLoop
P01 14	Surdo	P02 14	NaturePerc	P03 18	Turk-Mitry	P05 05	Bs Marimba	P06 14	Jazz Mix	P07 14	TechNow	P08 11	SFX Menu 1	P10 05	Asian Loop
P01 15	ESCOLA	P02 15	GyliBalaph			P05 06	TubularBel	P06 15	JzBrush&Bs	P07 15	Sweep 808	P08 12	SFX Menu 2	P10 06	FusionLoop
P01 16		P02 16	TalkDrm II	ASIAN		P05 07	Timpani	P06 16	BluesClub	P07 16	Revolution	P08 13	SFX Menu 3	P10 07	Dance Loop
P01 17	Pandeiroll	P02 17	PotDrum II	P04 01	JAPAN	P05 08	Orch Hit	P06 17	Drum&Horns	P07 17	Backbeat			P10 08	Shot & Tap
P01 18	Surdo II			P04 02	MATSURI	P05 09	LightOrch	P06 18	TechnoGate	P07 18	AmberWater	OTHERS			
P01 19		INDIAN		P04 03	CHINA	P05 10	OrchPerc	P06 19	FlangeDrms	P07 19	SynthDrums	P09 01	Laserwave		
P01 20		P03 01	Tabla	P04 04	Yang Qin	P05 11	Aux Perc	P06 20	JunkyDrums	P07 20	Discotica	P09 02	Heavy Gtr		
P01 21	SpaceConga	P03 02	Dholak	P04 05	Korean4Drm	l		P06 21	Brush Box	P07 21	Dance 6	P09 03	Acous Bass		
P01 22	808 Latin	P03 03	Madal	P04 06	Gamelan	l		l		P07 22	Lock Out	P09 04	SH101 Bass		

PRESET INSTRUMENTS

LATIN			L97	Caxixi		F51	Afro Feet		136-138	Sagat		A21-A23	Gu		ORCH			DRUMS			SFX		
L01-L05,L07	Bongo Hi	x 6	L98-I03	Berimbau	x 5	F52	Afro Stomp	x 1	139-141	Darbukka	x 3	A24-A25	Tang Gu	x 2	O01	Sleigh Bell	x 1	R01-R12	Kick	x 12	S23-S26	Shot	x 4
L06, L08	Bongo Lo	x 2	104-106	Caixa	x 3	F53-F54	Hand Drum	x 2	142-143	Doira	x 2	A26-A27	Hu Ÿin Luo	x 2	O02	Tree Chimes	x 1	R22-R34	Snare	x 22	S27-S36	Noise	x 10
L09-L18,			107-108	Rain Stick	x 2	F55-F57	Mongu	x 3	144-149	Doholla	x 6	A28	Nao Bo	x 1	O03-O04	Triangle	x 2	R35-R36	CrossStk	x 2		etc	x 50
L28-L29	Conga Hi	x 12	109	SambaBateria	x 1	F58	Clapstick	x 1	150-153	Rek	x 4	A29	Xiao Bo	x 1	O05	Castanets	x 1	R37-R42	Stick	x 6			
L19-L27,L30	Conga Lo	x 10	I10-I11	SpaceConga	x 2	F59	Boomerang	x 1	154	Bendir	x 1	A30	Large TamTam	1 x 1	O06-O07	Wood Block	x 2	R43-R56	Tom	x 14	OTHERS		
L31-L34	Cowbell	x 4	I12-I13	E.Conga	x 2	F60	Bamboo	x 1	155	Dawul	x 1	A31	Large Gong	x 1	O08	Slapstick	x 1	R57-R78	Hi-Hat	x 22	T01-T05	Piano	x 5
L35-L36	Claves	x 2	114-125	AnalogPercs	x 12	F61	BloomBell	x 1	156-157	HmrDlcmr	x 2	A32	Small Gong	x 1	O09-O10	Concert BsDr	x 2	R79-R96	Cymbal	x 18	T06-T07	Organ	x 2
L37-L40	Guiro	x 4										A33	Bend Gong	x 1	011	Timpani	x 1	R97	Wheel Pedal	x 1	T08-T28	Guitar	x 21
L41	Maracas	x 1	AFRICAN						ASIAN			A34	Yang Qin	x 1	012	Perc Hit	x 1	R98-r01	KickCymbal	x 3	T29-T41	Bass	x 13
L42-L44	Shaker	x 3	F01	Shekere	x 1	INDIAN			A01	Biwa	x 1	A35-A36	Finger Cym	x 2	O13-O14	Orch Hit	x 2	r02	Voice Kick	x 1	T42-T44	Strings	x 3
L45-L46	Tambourine	x 2	F02-F07	Djembe	x 6	101	Sama Bell	x 1	A02	Atarigane	x 1	A37	Rama Cymbal	x 1	O15	DrmMaj Whstl	x 1	r03	Voice Snare	x 1	T45-T50	Brass	x 6
L47-L59	Timbale	x 13	F08-F13	Small Djembe	x 6	102-109	Tabla	x 8	A03	Hyoshigi	x 1	A38-A40	Chenchen	x 3	O16	Glockenspiel	x 1	r04	Voice HiHat	x 1	T51	Tenor sax	x 1
L60	Vibra-slap	x 1	F14-F16	TalkingDrm	x 3	I10-I14	Baya	x 5	A04	Ohkawa	x 1	A41-A43	Bali Cym	x 3	017	Vibraphone	x 1				T52	Flute	x 1
L61-L62	Steel Drum	x 2	F17-F20	Afro Drum	x 4	115-119	Dholak	x 5	A05-A06	Tsuzumi	x 2	A44	Thai Gong	x 1	O18	Xylophone	x 1	DANCE			T53-T58	Wave	x 6
L63-L69	Agogo	x 7	F21	Metal Casta	x 1	120-123	Madal	x 4	A07-A08	Shime Taiko	x 2	A45-A47	JawsHarp	x 3	O19-O20	Marimba	x 2	D01-D05	Hand Clap	x 5	T59-T68	Synth	x 10
L70	Cabasa	x 1	F22-F31	Pot Drum	x 10	124	Khole	x 1	A09-A10	MatsuriTaiko	x 2	A48	Bonang	x 1	O21	Bass Marimba	x 1	D06-D12	Scratch	x 7			
L71-L78	Cuica	x 8	F32	Kalimba	x 1	125-128	Dhol	x 4	A11-A12	Buk	x 2	A49	Gender	x 1	O22	Celesta	x 1	D15-D18	Trash	x 4			
L79-L84	Pandeiro	x 6	F33	Log Drum	x 1	129-130	Sitar	x 2	A13	Jang-Gu	x 1	A50	Saron	x 1	O23	Tubular Bell	x 1	D19-D21	High-Q	x 3			
L85-L89	Surdo	x 5	F34-F41	Gyilli	x 8	131-132	Santoor	x 2	A14-A15	Jing	x 2	A51	Angklung	x 1	O24	Glass	x 1	D29-D36	Hit	x 8			
L90-L93	Tamborim	x 4	F42-F49	Balaphone	x 8	133-134	Tambura	x 2	A16-A17	Gengari	x 2	A52-A53	Gamelan	x 2	O25	Iron Hammer	x 1		etc	x 18			
L94-L96	Whistle	x 3	F50	Afro Zither	x 1	135	Bell Tree	x 1	A18-A20	Ban Gu	х 3												

Personal Monitor Amplifier



A Monitor Built for Electronic Percussion.

The PM-1 is the perfect monitoring system for Roland's SPD-Series and HPD-15 HandSonic. Precisely tuned for the needs of acoustic and electronic percussionists, the PM-1's 60-watt amplifier and 2-way speaker system sound great on stage or at home. And monitoring is easy, thanks to a smart angled design that even accommodates drum stands.







Pads

V-Pads™ PD-120/100/80R/80 Dual-Trigger Pads

PD-9/7
Single-Trigger Pad
PD-6

Extension pads for the SPD-S, SPD-20, and HPD-15, allowing users to trigger additional sounds using high-quality "mesh" or rubber drum heads. PD-120 and PD-100 pads available in red or purple.



▲ PD-9

Kick Triggers

V-Kicks **KD-120/80**

KD-120 kick available in red or purple.

Kick Trigger Unit

*Beater and connection cable included.
*Kick drum pedal not included and shown only for photography purposes.



Cymbals

V-Cymbals™ CY-12R/C, CY-14C, CY-15R, CY-12H

Dynamic crash, ride and hi-hat cymbals designed to faithfully recreate acoustic cymbal dimensions, movements and inertia.



Dual-Trigger Cymbal Pad **CY-6**

Affordable dual-trigger crash/ride cymbal with natural "swinging" motion and super-accurate triggering.

Pad Stand

Pad Stand PDS-15

Slant-type stand designed for hand percussion products like the HPD-15 and SPD-6.

➤ Setup Example PDS-15 can be slanted to improve HPD-15's playability.



Acoustic Drum Triggers



Kick Trigger **RT-7K**



Snare Trigger RT-5S Trigger: 2 (head, rim)



Tom Trigger RT-3T

Trigger MIDI Converter

Trigger MIDI Converter **TMC-6**

An affordable way to play and trigger MIDI modules and samplers from an acoustic drum set, or expand the capabilities of an electronic set.



Others



Hi-Hat Control Pedal **FD-7**



All Purpose Clamp **APC-33**

Heavy-duty mounting clamp for use with the SPD-S/20/6 and the HPD-15.



Pedal Switch



Footswitch DBDSS

Connection Cable PCS-31





Expression Pedal EV-5



Stereo Headphone RH-50



Visit us online at www.Roland.com

All specifications and appearances are subject to change. All trademarks used in this catalog are the property of their respective companies.